

Using data file "PKPlusDeviceFile.dat" which is a version 3.63.239.6 file.

PICkitCommandline v6.18.24050.8697

PIC32MX460F512L	0x00078000	Others/PIC32	16		
PIC32MX460F256L	0x00074000	Others/PIC32	16		
PIC32MX440F512H	0x00056000	Others/PIC32	16		
PIC32MX440F256H	0x00052000	Others/PIC32	16		
PIC32MX440F128L	0x0006D000	Others/PIC32	16		
PIC32MX440F128H	0x0004D000	Others/PIC32	16		
PIC32MX420F032H	0x00042000	Others/PIC32	16		
PIC32MX360F512L	0x00038000	Others/PIC32	16		
PIC32MX360F256L	0x00034000	Others/PIC32	16		
PIC32MX340F512H	0x00016000	Others/PIC32	16		
PIC32MX340F256H	0x00012000	Others/PIC32	16		
PIC32MX340F128L	0x0002D000	Others/PIC32	16		
PIC32MX340F128H	0x0000D000	Others/PIC32	16		
PIC32MX320F128L	0x0002A000	Others/PIC32	16		
PIC32MX320F128H	0x0000A000	Others/PIC32	16		
PIC32MX320F064H	0x00006000	Others/PIC32	16		
PIC32MX320F032H	0x00002000	Others/PIC32	16		
PIC32MX250F128B	0x04D00053	Others/PIC32	16		
PIC32MX230F064B	0x04D01053	Others/PIC32	16		
PIC32MX220F032B	0x04A00053	Others/PIC32	16		
PIC32MX210F016B	0x04A01053	Others/PIC32	16		
PIC32MX150F128B	0x04D06053	Others/PIC32	16		
PIC24HJ64GP510	0x0000004B	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP506	0x00000049	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP504	0x00000677	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP502	0x00000675	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP210	0x00000047	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP206	0x00000041	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP204	0x00000657	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ64GP202	0x00000655	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ32GP304	0x00000647	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ32GP302	0x00000645	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ32GP204	0x00000F1F	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ32GP202	0x00000F1D	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ256GP610 (A)	0x0000077B	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ256GP610	0x0000007B	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ256GP210 (A)	0x00000773	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ256GP210	0x00000073	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ256GP206 (A)	0x00000771	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ256GP206	0x00000071	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ16GP304	0x00000F17	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ12GP202	0x0000080B	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ12GP201	0x0000080A	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP510	0x00000063	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP506	0x00000061	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP504	0x0000067F	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP502	0x0000067D	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP310	0x00000067	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP306	0x00000065	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP210	0x0000005F	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP206	0x0000005D	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP204	0x00000667	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24HJ128GP202	0x00000665	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24FV32KA304	0x00004517	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24FV32KA302	0x00004513	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24FV32KA301	0x00004519	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24FV32KA301	0x00004519	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC24FV16KA304	0x00004507	Others/PIC24	1	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application

PIC18F65K80	0x00006140	PIC18/PIC18F_K90_K80_K22	19	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65K40	0x00006800	PIC18/PIC18F_MSB1st	22	*	
PIC18F65K22	0x00005300	PIC18/PIC18F_K90_K80_K22	19	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65J94	0x00006400	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65J90	0x00003860	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65J50	0x00004100	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65J15	0x00001540	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65J11	0x00003960	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F65J10	0x00001520	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6585	0x00000A60	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6527	0x00001340	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6525	0x00000AE0	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6520	0x00000B20	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F64J90	0x00003820	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F64J11	0x00003920	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6493	0x00000E00	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6490	0x000006A0	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6410	0x000006E0	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F63J90	0x00003800	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F63J11	0x00003900	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6393	0x00001A00	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6390	0x00000BA0	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F6310	0x00000BE0	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F57Q84	0x00009905	PIC18/PIC18F_MSB1st	22	*	
PIC18F57Q83	0x0000990B	PIC18/PIC18F_MSB1st	22	*	
PIC18F57Q43	0x000074C0	PIC18/PIC18F_MSB1st	22	*	
PIC18F57K42	0x00006B80	PIC18/PIC18F_MSB1st	22	*	
PIC18F56Q84	0x0000A302	PIC18/PIC18F_MSB1st	22	*	
PIC18F56Q83	0x0000A308	PIC18/PIC18F_MSB1st	22	*	
PIC18F56Q71	0x00007760	PIC18/PIC18F_MSB1st	22	*	
PIC18F56Q43	0x00007460	PIC18/PIC18F_MSB1st	22	*	
PIC18F56K42	0x00006BA0	PIC18/PIC18F_MSB1st	22	*	
PIC18F55Q71	0x00007860	PIC18/PIC18F_MSB1st	22	*	
PIC18F55Q43	0x00007400	PIC18/PIC18F_MSB1st	22	*	
PIC18F55K42	0x00006BC0	PIC18/PIC18F_MSB1st	22	*	
PIC18F54Q71	0x00007820	PIC18/PIC18F_MSB1st	22	*	
PIC18F47Q84	0x00009904	PIC18/PIC18F_MSB1st	22	*	
PIC18F47Q83	0x0000990A	PIC18/PIC18F_MSB1st	22	*	
PIC18F47Q43	0x000074A0	PIC18/PIC18F_MSB1st	22	*	
PIC18F47Q10	0x000070E0	PIC18/PIC18F_MSB1st	22	*	
PIC18F47K42	0x00006BE0	PIC18/PIC18F_MSB1st	22	*	
PIC18F47K40	0x00006900	PIC18/PIC18F_MSB1st	22	*	
PIC18F47J53	0x000058E0	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F47J13	0x000059E0	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46Q84	0x0000A301	PIC18/PIC18F_MSB1st	22	*	
PIC18F46Q83	0x0000A307	PIC18/PIC18F_MSB1st	22	*	
PIC18F46Q71	0x00007720	PIC18/PIC18F_MSB1st	22	*	
PIC18F46Q43	0x00007440	PIC18/PIC18F_MSB1st	22	*	
PIC18F46Q10	0x00007120	PIC18/PIC18F_MSB1st	22	*	
PIC18F46K80	0x00006100	PIC18/PIC18F_K90_K80_K22	19	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46K50	0x00005D00	PIC18/PIC18F_K_	6	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46K42	0x00006C00	PIC18/PIC18F_MSB1st	22	*	
PIC18F46K40	0x00006920	PIC18/PIC18F_MSB1st	22	*	
PIC18F46K22	0x00005400	PIC18/PIC18F_K_	6	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46K20	0x00002000	PIC18/PIC18F_K_	6	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46J53	0x000058A0	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46J50	0x00004CA0	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46J13	0x00005BA0	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F46J11	0x00004E20	PIC18/PIC18F_J_	4	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC18F4685	0x00002760	PIC18/PIC18F	3	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application

PIC16C83	0x00003FE0	Midrange/NoDeviceId	20	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1840	0x00001BC0	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1822	0x00002800	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1612	0x00003059	Midrange/1.8v MinII	18	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1572	0x00003052	Midrange/1.8v MinII	18	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1571	0x00003053	Midrange/1.8v MinII	18	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1552	0x00002BC0	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12LF1501	0x00002D80	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12HV752	0x00001520	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12HV615	0x000021A0	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12HV609	0x00002280	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F752	0x00001500	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F683	0x00000460	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F675	0x00000FC0	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F635	0x00000FA0	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F629	0x00000F80	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F617	0x00001360	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F615	0x00002180	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F609	0x00002240	Midrange/Standard	0	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F519	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F510	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F509	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F508	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F1840	0x00001B80	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F1822	0x00002700	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F1612	0x00003058	Midrange/1.8v MinII	18	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F1572	0x00003050	Midrange/1.8v MinII	18	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F1571	0x00003051	Midrange/1.8v MinII	18	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC12F1501	0x00002CC0	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10LF322	0x000029C0	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10LF320	0x000029E0	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F322	0x00002980	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F320	0x000029A0	Midrange/1.8V Min	14	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F222	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F220	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F206	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F204	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F202	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
PIC10F200	0x0000FFFF	Baseline	2	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
MCP25055	0xFFFFFFFF	Others/MCP250xx	17	*	
MCP25050	0xFFFFFFFF	Others/MCP250xx	17	*	
MCP25025	0xFFFFFFFF	Others/MCP250xx	17	*	
MCP25020	0xFFFFFFFF	Others/MCP250xx	17	*	
M25P80	0xFFFFFFFF	EEPROMS/25LC	11	*	
M25P64	0xFFFFFFFF	EEPROMS/25LC	11	*	
M25P40	0xFFFFFFFF	EEPROMS/25LC	11	*	
M25P32	0xFFFFFFFF	EEPROMS/25LC	11	*	
M25P20	0xFFFFFFFF	EEPROMS/25LC	11	*	
M25P16	0xFFFFFFFF	EEPROMS/25LC	11	*	
M25P10	0xFFFFFFFF	EEPROMS/25LC	11	*	
HCS362	0xFFFFFFFF	Others/KEELOQ?? HCS	9	*	
HCS361	0xFFFFFFFF36	Others/KEELOQ?? HCS	9	*	
HCS360	0xFFFFFFFF36	Others/KEELOQ?? HCS	9	*	
HCS320	0xFFFFFFFF	Others/KEELOQ?? HCS	9	*	
HCS301	0xFFFFFFFF	Others/KEELOQ?? HCS	9	*	
HCS300	0xFFFFFFFF	Others/KEELOQ?? HCS	9	*	
HCS201	0xFFFFFFFF	Others/KEELOQ?? HCS	9	*	
HCS200	0xFFFFFFFF	Others/KEELOQ?? HCS	9	*	
dsPIC33FJ64MC804	0x0000061B	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33FJ64MC802	0x00000619	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application

dsPIC33FJ128GP206(A)	0x000000D9	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33FJ128GP204	0x00000627	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33FJ128GP202	0x00000625	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33FJ06GS202	0x00000C02	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33FJ06GS102	0x00000C01	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33FJ06GS101	0x00000C00	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC33EP32GP502	0x00001C0D	Others/dsPIC33	5	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F6015	0x00000280	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F6014A	0x000002C3	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F6013A	0x000002C1	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F6012A	0x000002C2	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F6011A	0x000002C0	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F6010A	0x00000281	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F5016	0x00000201	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F5015	0x00000200	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F5013	0x00000081	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F5011	0x00000080	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F4013	0x00000141	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F4012	0x00000100	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F4011	0x00000101	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F3014	0x00000160	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F3013	0x000000C3	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F3012	0x000000C1	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F3011	0x000001C1	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F3010	0x000001C0	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F2023	0x00000403	Others/dsPIC30 SMPS	8	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F2020	0x00000400	Others/dsPIC30 SMPS	8	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F2012	0x00000241	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F2011	0x00000240	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F2010	0x00000040	Others/dsPIC30	7	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
dsPIC30F1010	0x00000404	Others/dsPIC30 SMPS	8	*	Supports Programmer to Go - PICKit2 Only with PICKitPlus GUI application
93LC86B (C x16)		EEPROMS/93LCx	0xFFFFFFFF	13	
93LC86A (C x8)		EEPROMS/93LCx	0xFFFFFFFF	12	
93LC76B (C x16)		EEPROMS/93LCx	0xFFFFFFFF	13	
93LC76A (C x8)		EEPROMS/93LCx	0xFFFFFFFF	12	
93LC66B (C x16)		EEPROMS/93LCx	0xFFFFFFFF	13	
93LC66A (C x8)		EEPROMS/93LCx	0xFFFFFFFF	12	
93LC56B (C x16)		EEPROMS/93LCx	0xFFFFFFFF	13	
93LC56A (C x8)		EEPROMS/93LCx	0xFFFFFFFF	12	
93LC46B (C x16)		EEPROMS/93LCx	0xFFFFFFFF	13	
93LC46A (C x8)		EEPROMS/93LCx	0xFFFFFFFF	12	
25LC640A	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC512	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC320A	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC256	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC160B	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC160A	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC128	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC1024	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC080B	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC080A	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC040A	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC020A	0xFFFFFFFF	EEPROMS/25LC	11	*	
25LC010A	0xFFFFFFFF	EEPROMS/25LC	11	*	
24xx64	0xFFFFFFFF	EEPROMS/24xx	10	*	
24xx512	0xFFFFFFFF	EEPROMS/24xx	10	*	
24xx32	0xFFFFFFFF	EEPROMS/24xx	10	*	
24xx256	0xFFFFFFFF	EEPROMS/24xx	10	*	
24xx16	0xFFFFFFFF	EEPROMS/24xx	10	*	
24xx128	0xFFFFFFFF	EEPROMS/24xx	10	*	

24xx1026	0xFFFFFFFF	EEPROMS/24xx	10	*
24xx1025	0xFFFFFFFF	EEPROMS/24xx	10	*
24xx08	0xFFFFFFFF	EEPROMS/24xx	10	*
24xx04	0xFFFFFFFF	EEPROMS/24xx	10	*
24xx02	0xFFFFFFFF	EEPROMS/24xx	10	*
24xx01	0xFFFFFFFF	EEPROMS/24xx	10	*
24xx00	0xFFFFFFFF	EEPROMS/24xx	10	*
24LC32A	0xFFFFFFFF	EEPROMS/24xx	10	*
24LC16B	0xFFFFFFFF	EEPROMS/24xx	10	*
24LC08B	0xFFFFFFFF	EEPROMS/24xx	10	*
24LC04B	0xFFFFFFFF	EEPROMS/24xx	10	*
24LC02B	0xFFFFFFFF	EEPROMS/24xx	10	*
24LC01B	0xFFFFFFFF	EEPROMS/24xx	10	*
11LC160	0xFFFFFFFF	EEPROMS/11LC	15	*
11LC080	0xFFFFFFFF	EEPROMS/11LC	15	*
11LC040	0xFFFFFFFF	EEPROMS/11LC	15	*
11LC020	0xFFFFFFFF	EEPROMS/11LC	15	*
11LC010	0xFFFFFFFF	EEPROMS/11LC	15	*
+FL127S	0xFFFFFFFF	EEPROMS/25LC	11	*

* Supported by PKCMD, PKAutoWatch, PKGangProgrammer and PKCMD-LX.

All devices are supported by PICKit2Plus and PICKit3Plus applications.